

Product Data

CENTURION I

Foaming Germicidal Cleaner

Formulated to Disinfect:

- Walls
- Sink Tops
- Tables
- Chairs
- Telephones
- Bathrooms
- Shower Stalls
- Bathtubs
- Hampers
- Cabinets
- Bed Springs
- Pet Animal Quarters

For Use in the Following Areas:

Homes, Nursing Homes, Hospitals, Institutions, Offices, Schools, Hotels & Motels, Garbage Storage Areas, Veterinary Clinics, Kennels, Zoos

CENTURION I is formulated to disinfect inanimate hard surfaces. It deodorizes those areas which generally are hard to keep fresh smelling and other areas which are prone to odors caused by microorganisms. CENTURION I demonstrates effective disinfection against *Staphylococcus aureus*, Methicillin Resistant *Staphylococcus aureus* (MRSA), HIV-1 (Aids Virus), Canine Parvovirus, *Legionella pneumophila*, and Influenza A H1N1. This product is fungicidal against Pathogenic fungi (*T. mentagrophytes*). It also controls mold, mildew and the odors they cause on hard, non-porous, inanimate surfaces when used as directed.

- ✓ May Be Used as a General Cleaner to Disinfect and Deodorize and as a Mildewstat to Control Mold and Mildew Growth
- ✓ Demonstrates Effective Disinfection Against *Staphylococcus aureus*, Methicillin Resistant *Staphylococcus aureus* (MRSA), *Salmonella enterica*, *Pseudomonas aeruginosa*, HIV-1 (Aids Virus), Canine Parvovirus, Herpes simplex type 1, Herpes simplex type 2, *Legionella pneumophila*, and Influenza A H1N1
- ✓ Cleans as it Disinfects Glazed Porcelain, Formica, Glazed Tile, Vinyl, Stainless Steel, Finished Woodwork and Other Hard, Non-Porous Surfaces



...setting performance standards worldwide...

APPLICATIONS

When used as directed, this product demonstrates effective disinfection against Staphylococcus aureus, Methicillin Resistant Staphylococcus aureus (MRSA), Salmonella enterica, Pseudomonas aeruginosa, Canine Parvovirus, Herpes simplex type 1, Herpes simplex type 2, Legionella pneumophila, and Influenza A H1N1, thus meeting requirements for hospital use. Efficacy tests have demonstrated that the product is an effective one-step cleaner disinfectant in the presence of organic soil (5% blood serum). This product is fungicidal against Pathogenic fungi (T. mentagrophytes), when used as directed on hard surfaces found in the bathroom, shower stall, and locker room, or other clean, hard, non-porous surfaces commonly contacted by bare feet. This product is a versatile disinfectant and virucide for veterinarian and animal care applications when used as directed below. This product can be used in veterinary clinics, animal life science laboratories, kennels, dog/cat animal kennels, breeding and grooming establishments, pet animal quarters, zoos, pet shops, tack shops and other animal care facilities. **MOLD AND MILDEWSTAT:** This product controls mold, mildew and the odors they cause on hard, non-porous, inanimate surfaces when used as directed.

DIRECTIONS

It is a violation of Federal law to use this product in a manner inconsistent with its labeling. **DISINFECTION, DEODORIZATION AND CLEANING:** This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to preclean or decontaminate critical or semi-critical medical devices prior to sterilization or high level disinfection. Surfaces which come into contact with food must be rinsed with potable water after disinfection. Do not use this product to disinfect appliances, refrigerator interiors, microwave interiors. Do not use this product to disinfect or clean dishes, glassware or eating utensils. To disinfect hard non-porous surfaces (such as glazed bathroom tiles, walls, fixtures, shower stalls, sinks, bathtubs, hampers, tables, chairs, HVAC catchpans and air conditioning evaporator coils), proceed as indicated below: (1) Shake can before using. (2) Hold six to eight inches from surface to be treated. (3) Spray area until it is covered with a white foam. Allow foam to penetrate and remain wet for 10 minutes. No scrubbing necessary. (4) Wipe off with a clean cloth, mop or sponge. This product will not leave grit or soap scum. For heavily soiled areas, remove gross soil before treatment. For animal quarters and kennels, veterinary clinics, animal life science laboratories, pet shops, kennels, breeding and grooming establishments, tack shops: Remove all animals, poultry, and their feed/food from premises. Remove all litter, droppings and manure from all surfaces to be treated. Apply as directed above. This product will disinfect and clean the following surfaces: Equipment, utensils, instruments, cages, kennels, stables, stalls and catteries. After disinfection, ventilate buildings, coops and other closed spaces. Do not house poultry, or other animals or employ equipment until treatment has been absorbed, set or dried. All treated equipment that will contact feed or drinking water (racks, troughs, automatic feeders, fountains, waterers and other similar equipment) must be thoroughly scrubbed with soap or detergent then rinsed with potable water before reuse. **MILDEWSTAT:** To control mold and mildew on pre-cleaned, hard, non-porous surfaces (such as floors, walls, table tops) spray surfaces to be treated, making sure to wet completely. Let

air dry. Repeat application at weekly intervals or when mildew growth reappears. **KILLS HIV-1 (AIDS VIRUS) ON PRECLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS** in healthcare settings or other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or body fluids, and in which the surfaces/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of human immunodeficiency virus Type 1 (HIV-1) (associated with AIDS). **SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 (AIDS VIRUS) OF SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS.** Personal Protection: Disposable latex or vinyl gloves, gowns, face masks, or eye coverings as appropriate, must be worn during all cleaning of body fluids, blood and decontamination procedures. Cleaning procedures: Blood and body fluids must be thoroughly cleaned from surfaces and objects before application of disinfectant. Contact Time: Effective against HIV-1 (AIDS virus) on hard non-porous surfaces in the presence of a moderate amount of organic soil (5% blood serum) providing 1800 ppm of active quaternary water for a contact time of 10 minutes at room temperature (20-25°C). Use a ten (10) minute contact time for disinfection against all other bacteria and fungi claimed (listed on labeling). Disposal of Infectious Materials: Blood and other body fluids should be autoclaved and disposed of according to federal, state, and local regulations for infectious waste disposal.

TECHNICAL DATA

ACTIVE INGREDIENTS:

n-Alkyl (60% C14, 30% C16, 5% C12, 5% C18) dimethyl benzyl ammonium chloride	0.10%
n-Alkyl (68% C12, 32% C14) dimethyl ethylbenzyl ammonium chloride	0.10%
OTHER INGREDIENTS:	99.80%
TOTAL	100.000%

APPROVALS

EPA Reg. No. 44446-23-13051

ATCO
INTERNATIONAL

*...setting performance
standards worldwide...*

C-6/PC-2511/0622